

# ACCUSPLIT®

## 605XE EVENT STOPWATCH OPERATING INSTRUCTIONS



### EVENT STOPWATCH

- A or C → Start
- A or C → Stop (time out)
- A or C → Restart (time in)
- A or C → Stop
- B → Reset

### SPECIFICATIONS

#### Operating Temperature


14°F to 138°F (-10°C to 59°C)

#### Quartz Crystal Accuracy

±0.002% (accuracy may vary with shock, temperature, or aging of crystal).

#### Batteries

Batteries should last for 3 years. If display becomes dim, open back and replace with Duracell D357, Eveready D357, or Ray-O-Vac RW42.



#### NO-PROOF-OF-PURCHASE LIMITED WARRANTY

See label on back of unit for details, or check  
<http://support.ACCUSPLIT.com>

ACCUSPLIT, Inc. • 6120 Stoneridge Mall Rd., Suite 210 • Pleasanton, CA 94588 USA  
800-965-2008 • 925-226-0888 • FAX 925-463-0147 • [www.ACCUSPLIT.com](http://www.ACCUSPLIT.com) • [support@ACCUSPLIT.com](mailto:support@ACCUSPLIT.com)